



DIY INGREDIENTS
1020400



Citric Acid

Powder

Appliances, tapware, scaled surfaces (indoor & outdoor)

- ✓ Dissolves limescale, restores shine, removes rust, boosts other cleaners
- ✓ 100% naturally derived ingredients, ECOCERT certified
- ✓ Indicative time: 20 min for descaling appliances

FEATURES

The powerful natural anti-limescale solution. A plant-based acid naturally present in lemons, it dissolves heavy limescale, makes tapware shine, and protects household appliances to extend their lifespan.

INSTRUCTIONS FOR USE

- ✓ Washing machine or dishwasher: pour 6 to 8 tablespoons into the drum or tub and run an empty cycle at 60 °C minimum.
- ✓ Kettles & coffee makers: dissolve 1 to 2 tablespoons in 1 L of water. Fill the appliance, leave to act for 30 min without heating, then rinse twice with clean water.

RECOMMENDATIONS

- ✓ Never use on marble, enamel, aluminium, or natural stone.
- ✓ Wearing gloves and safety glasses recommended.
- ✓ Store in a dry place.
- ✓ Keep out of reach of children.

Detergent certified by ECOCERT Greenlife according to the ECOCERT 'Ecodetergent' standard available at <http://detergents.ecocert.com>

* The product or its components are not derived from organic farming. The term 'bio' or 'biological' refers to enzymes derived from microbiological organisms.

REF. BEVIL	DESIGNATION	EAN CODE	CONTAINER	CU
1020400	Citric Acid	 5400258204000	400 g	4